




CEMB

SAFETY MACHINES

EN *User's manual*



C212


CEMB S.p.A.

Via Risorgimento, 9 - 23826 Mandello del Lario (LO) ITALY


Telefono: + 39 0341 706369 Fax: + 39 0341 700725 www.cemb.com - garage@cemb.com

Cemb SpA declines all liability for any damage to people or property caused by incorrect use of this product.
Subject to change without prior notice.

 **CEMB**



Dichiarazione CE di Conformità
 Declaration of Conformity
 EG-Konformitäts-Erklärung
 Déclaration de Conformité
 Declaración de Conformidad CE
 Declaração CE de Conformidade



EC-Verklaring van Overeenstemming
 Försäkran om CE-överensstämmelse
 CE-overensstemmelses-erklæring
 CE-overensstemmelses-erklæring
 CE-vaatimuskaisuus-vakuutus
 Δήλωση Συμμόρφωσης CE

La Ditta
 The Company
 Die Firma
 La Maison
 La Companhia
 A Empresa



Het bedrijf
 Företaget
 Virksomheden
 Virksomheten
 Yhtiö
 Η εταιρία

dichiara con la presente la conformità del Prodotto
 herewith declares conformity of the Products
 erklärt hiermit die Konformität des Produkts
 déclare par la présente la conformité du Produit
 Declare la conformidad del Producto
 com a presente declara a conformidade do Produto

verklaart bij deze de overeenstemming van het product
 försäkrar härmed att produkten
 erklærer herved, at produktet
 bekræfter herved at produktet
 vakuuttaa että tuote
 Δηλώνει με την παρούσα τη συμβατότητα του Προϊόντος

Equilibratrice Balancer Auswuchtmaschine Equilibreuse Balanceadora Máquina de equilibrar	Balanceerapparaat Balanseringsmaskin Hjulbalanceringsmaskine Balanseringsmaskin Tasapainotuskone Ζυγοσταθμιστής
---	--

Tipo
 Type
 Typ
 Type
 Tipo
 Tipo

C212

Nr. di serie
 Serial Number
 Fabriknummer, usw
 Número de série
 Numero de fabricación
 Número de série

B

Serienummer
 Serienr
 Serienr
 Serienr
 Sarjanno
 Αρ. Σειράς

Numero Distinta Base
 Manufacturing List Number
 Erstellungsliste nummer
 Número de lista de construcción
 Numero lista de base
 Número da Lista de Base

Pr 693

Nummer basislijst
 Produktionslistans nr.
 Produktionslistans nr.
 Produktionslistans nr.
 Valmistusluettelon nro.
 Αριθμός Καταλόγου Παραγωγής

alle norme sottostanti / with applicable regulations below / mit folgenden einschlägigen Bestimmungen / selon les normes ci-dessous / con directivas subaplicables / com as normas indicadas em baixo / met de onderstaande normen / överensstämmer med följande föreskrifter / stemmer överens med følgende forskrifter / om yhdenmukainen seuraavissa laeissa olevien ehtojen kanssa / στους παρακάτω κανονισμούς

D.P.R. Nr. 459, allegato 1 del 24 Luglio 1996

Directive CEE / EC Directive / EG Richtlinie / Directive CEE / Directivas CE / Directivas CEE / EEG-richtlijnen
 EU-direktiv / EØF-direktiver / EU-direktiver / EU-direktiv / Οδηγίες CEE

98/37/CEE - 73/23/CEE - 93/68/CEE - 89/336/CEE

Norme Armonizzate Adottate / Applied Harmonized Standards / Angewendete Harmonisierte Normen / Normes Harmonisées Appliquées / Normas Aplicadas en Conformidad / Normas Harmonizadas Aplicadas / Toegepaste geharmoniseerde richtlijnen / Standarder / Standardit / Εναρμονισμένα Εφαρμοζόμενα Κανονισμοί


EN 12100-1:2005	X	EN 12100-2:2005	X	EN 294:1993	X	EN 349:1993	X
EN 418:1992	X	EN 457 :1993	X	EN 60204-1:2006	X	EN 60439-1:1990	X
EN 61000-6-3/A11:2005	X	EN 61000-6-1/IS1:2006	X	EN 61000-6-4-:2002	X	EN 61000-6-2:2006	X

Data / Date / Datum / Date / Fecha / Data
 Datum / Datum / Date / Pvm / Ημερομηνία

Firma / Signature / Unterschrift / Signature / Firma / Assinatura
 Handtekening / Underskrift / Allekirjoitus / Υπογραφή

14/07/2009	CEMB Spa Il Presidente Ing. Carlo Buzzi	
------------	--	--

M06PRG01





CONTENTS

1 - GENERAL	3
1.1 - GENERAL SAFETY REGULATIONS	3
1.1.1 - STANDARD SAFETY DEVICES	3
1.2 - FIELD OF APPLICATION	3
1.3 - MAIN PARTS	3
1.4 - OVERALL DIMENSIONS	3
1.5 - TECHNICAL DATA	4
2 - HANDLING AND LIFTING	4
3 - START - UP	5
3.1 - ELECTRICAL CONNECTION	5
3.2 - PNEUMATIC CONNECTION	5
3.3 - ADAPTER MOUNTING	5
3.4 - WHEEL MOUNTING	5
3.5 - WHEEL GUARD ASSEMBLY AND ADJUSTMENT (OPTION)	5
3.6 - LIFT	5
4 - CONTROLS AND COMPONENTS	6
4.1 - CONTROL PANEL AND DISPLAY	8
4.2 - AUTOMATIC DISTANCE AND DIAMETER GAUGE	6
5 - USE OF THE WHEEL BALANCER	7
5.1 - DATA SETTING	7
5.2 - RESULT OF MEASUREMENT	8
5.2.1 - STATIC UNBALANCE	8
5.2.2 - MODIFYING SET DIMENSIONS	8
5.2.3 - EXACT POSITIONING OF THE ADHESIVE WEIGHT BY MEANS OF THE GAUGE WITH CLIPS	8
5.2.4 - OPPOSITE POSITION	9
5.2.5 - SPLIT FUNCTION (HIDDEN ADHESIVE WEIGHTS)	9
5.2.6 - UNBALANCE OPTIMIZATION	10
5.2.7 - AUTOMATIC MINIMIZATION OF STATIC UNBALANCE	10
6 - SET UP	11
6.1 - MENU	11
6.2.1 - RIM DISTANCE GAUGE	12
6.2.2 - DIAMETER GAUGE	12
6.3 - BALANCING MACHINE CALIBRATION	13
7 - ERRORS	14
7.1 - INCONSISTENT UNBALANCE READINGS	15
8 - ROUTINE MAINTENANCE (see exploded drawings) (for non specialized personnel only)	15
8.1 - TO REPLACE THE DRIVING PULLEY	15
8.2 - TO REPLACE THE BRAKE PAD	15
8.3 - TO REPLACE THE FUSES	15
8.4 - MAINTENANCE OF THE PNEUMATIC CIRCUIT	15

1 - GENERAL

▶ 1.1 - GENERAL SAFETY REGULATIONS

- The machine should only be used by authorized and suitably trained personnel.
- Do not use the machine for purposes other than those specified in this manual.
- The machine should not be modified in any way except for those modifications explicitly carried out by specialised personnel.
- Never remove the safety devices. Any work on the machine should only be carried out by specialised personnel.
- Carefully clean the coupling surfaces before performing any operation.
- Avoid using strong jets of compressed air for cleaning.
- Use alcohol to clean the plastic panel or shelves (AVOID LIQUIDS CONTAINING SOLVENTS).
- Before starting the wheel balancing cycle, make sure that the wheel is securely locked on the adapter.
- The machine operator should avoid wearing clothes with flapping edges. Make sure that unauthorized personnel do not approach the machine during the work cycle.
- Avoid placing objects inside the cabinet as they could impair the correct operation of the machine.


▶ 1.1.1 - STANDARD SAFETY DEVICES

- Low rotation speed.
- STOP push button for stopping the wheel under emergency conditions.
- The safety guard (option) of high impact plastic is with shape and size designed to prevent risk of counterweights from flying out in any direction except towards the floor.
- A microswitch prevents starting the machine if the guard is not lowered and stops the wheel whenever the guard is raised.
- Protection system on LIFT control.


▶ 1.2 - FIELD OF APPLICATION

The machine is designed for balancing wheels of cars and motor vehicles weighing up to 250 kg. It can be operated in the temperature range of 0° to +45°C.

▶ 1.3 - MAIN PARTS



▶ 1.4 - OVERALL DIMENSIONS



► 1.5 - TECHNICAL DATA

Single-phase power supply	115 / 230 V 50/60 Hz
Protection class	IP 54
Max. power consumption	1,1 Kw
Balancing speed	100 r.p.m. for cars - 70 r.p.m. for trucks
Cycle time for average wheel	7±20 seconds
Balancing accuracy	1 gram for cars / 10 grams for trucks
Position resolution	± 1.4 °
Average noise	< 70dB (A)
Rim-machine distance	0 - 335 mm (400 mm max. presettable)
Rim width setting range	1.5" ± 20" or 40 ± 510 mm
Diameter setting range	10" ± 30" or 265 ± 765 mm
Max. wheel weight	250 kg.
Max. wheel diameter	1300 mm
Max. wheel width	495 mm (super single)
Min/max. compressed air pressure	8 ± 10 Kg/cm ²
	approx. 0.8 to 1 Mpa;
	approx. 8 to 10 BAR;
	approx. 115 to 145 PSI.
Air consumption per cycle	15 l. (at 8 Kg/cm ²)



2 - HANDLING AND LIFTING



*TO LIFT THE MACHINE, LEVER ONLY ON THE BASE WHERE THE 3 SUPPORT POINTS ARE LOCATED.
NEVER, UNDER ANY CIRCUMSTANCE, APPLY FORCE TO OTHER POINTS SUCH AS THE SPINDLE, HEAD, OR ACCESSORY SHELF.*

- Check that the balancing machine touches the floor at the three support points.
- It functions properly without having to fasten it to the floor with wheels weighing up to 160 kg; for heavier wheels, fasten it at the points indicated.

Options: *Front wheel translation KIT
Ground securing plate KIT*



3 - START - UP

▶ 3.1 - ELECTRICAL CONNECTION



THE ELECTRICAL CONNECTION MUST BE MADE BY SPECIALIZED PERSONNEL. CONNECTION TO THE SINGLE PHASE MAINS MUST BE MADE BETWEEN PHASE AND NEUTRAL, AND NEVER, UNDER ANY CIRCUMSTANCES, BETWEEN PHASE AND EARTH (GROUND). EFFICIENT EARTHING (GROUNDING) IS ESSENTIAL FOR CORRECT MACHINE OPERATION. THE MANUFACTURER DECLINES ALL RESPONSIBILITY AND WARRANTY IN THE EVENT OF INCORRECT CONNECTION.


Before connecting the machine to the mains through relative cable, check that the mains voltage matches the one shown on the nameplate at the back of the balancing machine. Rating of the electrical connection should be on the basis of the machine electrical power consumption (see nameplate).

- The machine mains supply cable should be fitted with a plug conforming to current regulations.
- It is recommended to provide the machine with its own electrical connection through a slow acting safety switch rated at 4 A (230 V) or 10 A (115 V).
- When connection is made directly to the main control panel without using any plug, it is advisable to padlock the main switch of the balancing machine in order to limit its use to authorized personnel only.

▶ 3.2 - PNEUMATIC CONNECTION

The machine must be connected to the compressed air supply and must not be used if the pressure is below 5 kg/cm² (5 bar; 72 PSI; 0.5 MPa). The maximum input pressure is limited to 10 kg/cm² (~10 Bar; ~145 PSI; ~1 MPa). The spinning and braking device is calibrated at the factory and cannot be modified.

▶ 3.3 - ADAPTER MOUNTING



- ▶ The wheel balancer is supplied complete with cone type adapter for fastening wheels with central bore. The threaded terminal is fitted according to the drawing; it can be removed to fit optional adapters. It can be removed to fit optional adapters.

▶ 3.4 - WHEEL MOUNTING

The wheels should be fastened with one of the numerous adapters manufactured by the manufacturer (see enclosed brochures). Incorrect centering inevitably causes unbalance.

▶ 3.5 - WHEEL GUARD ASSEMBLY AND ADJUSTMENT (option)

1. Fasten the components to the base as illustrated in the specific exploded drawing
2. The positions of these guards can be adjusted using the special screws accessed from inside the main support
3. With the guard closed check that the microswitch prod has slipped into place on the ring; to this end, adjust the angular position of the control ring if necessary.

▶ 3.6 - LIFT


The function of the lift is to make it easier to mount the wheel on the balancer spindle with the minimum manual effort. The pneumatic circuit of the machine has been designed to give the lift considerable flexibility of movement in any position along its travel. The lift is driven with the control pedal.



DURING LIFT MOVEMENT, KEEP AWAY FROM ITS RANGE OF ACTION.

4 - CONTROLS AND COMPONENTS

► 4.1 - CONTROL PANEL AND DISPLAY



- | | |
|-----|---|
| 1-2 | Digital readouts, AMOUNT OF UNBALANCE, inside/outside |
| 3-4 | Digital readouts, POSITION OF UNBALANCE, inside/outside |
| 5 | Indicators, correction mode selected |
| 6 | Indicators, selection made |
| 7 | Push button, unbalance reading < 5 g (25 oz) |
| 8 | Push button, car/truck selection |
| 9 | Push button, selection STATIC unbalance |
| 10 | Push button, SPLIT (unbalance spread) |
| 11 | Push button, FUNCTIONS MENU |
| 12 | Push button, menu selection confirmation |
| 13 | Push button, cycle start |
| 14 | Push button, emergency/home |
| 15 | Push button, position repeater |
| 16 | Manual dimension setting buttons |
| 17 | Push button to select grams/ounces as unit of measure for the unbalance |
| 18 | Digital display of the static unbalance value |
| 19 | Distance gauge position indication |
| 20 | Push button to select possible corrections |



- ONLY USE THE FINGERS TO PRESS THE PUSH BUTTONS.
- NEVER USE THE COUNTERWEIGHT PINNERS OR OTHER POINTED OBJECTS.

► 4.2 - AUTOMATIC DISTANCE AND DIAMETER GAUGE

Allows measuring the distance from the machine and the diameter at the point of application of the counterweight. The same gauge allows proper positioning of the counterweights inside using the specific function.


5 - USE OF THE WHEEL BALANCER

► 5.1 - DATA SETTING



Press the button  ; LED on   → balancing machine set in car mode

Press the button  ; LED on   → balancing machine set in truck mode

The balancing data is set by means of an "intelligent" automatic gauge; confirmation of the measurement and the position appear on the display. The round part of the gauge must rest on the rim where the weight will be positioned.




While the gauge is moving the following appears   ;

when the measurement has been stored  .

a) **standard weights:** When only one measurement is made, the machine interprets the presence of a rim with clip-on weight correction




The width value (b) must be set with the buttons   . The correct measurement is that which can be measured with the compass gauge provided.



b) **adhesive weights:** Make two successive measurements on two correction planes inside the rim.

The balancing machine automatically interprets that the correction will be made with adhesive weights and the following appears:




For a different combination of the type or position of the weights on the rim, use the button



► **5.2 - RESULT OF MEASUREMENT**

► **Unbalance display pitch:**


Car = 1/5 g (.1/0.25 Oz) Truck = 10/50 g (.25/1 Oz)

When  is pressed, the unbalance is displayed with pitch:


Car = 1 g Truck = 10 g
 .1 Oz .25 Oz

► **Unbalance display threshold**

Car = 5 g (.4 Oz) Truck = 50 g (2 Oz)




After performing a balancing spin, the amounts of unbalance are shown on the digital readouts. Digital readouts with LED lit up indicate the correct angular wheel position to mount the counterweights (12 o'clock position).

If the unbalance is less than the threshold selected, 0 is displayed instead of the unbalance; with  it is possible to read the values below the threshold chosen.


► **5.2.1 - STATIC UNBALANCE**

It is selected by pressing  and is shown on the central display. The position is indicated on the displays 3 and 4.


The value can always be displayed (see *SETUP*); in this case, to see the position press .



► **5.2.2 - MODIFYING SET DIMENSIONS**

If the wheel dimensions have been entered incorrectly, the parameters can be modified without repeating the balancing spin by pressing :




► **5.2.3 - EXACT POSITIONING OF THE ADHESIVE WEIGHT BY MEANS OF THE GAUGE WITH CLIPS**





- Press 
- Fit the correction weight in the specific gauge seat with the adhesive part facing upwards
- Bring the wheel into correct angular position for the plane to be corrected
- Lock the wheel in the correction position, by pressing the 
- Pull out the gauge; the approach of the weights to the correction positions is indicated by the LEDs number 19
- When the weight application distance has been reached a beep is sounded (can be deactivated).
- Turn the gauge until the correction weight adheres to the rim using the weight pusher.

► Fianco interno




Fianco esterno




To cancel this function, press  button again.

► 5.2.4 - OPPOSITE POSITION




► In the normal balancing condition the weight is applied at 12 o'clock and shown on the display.




► The balancing machine can also indicate the correction position on the bottom vertical line (see SETUP to select the O.P. function). This is very useful for correction of light alloy rims with adhesive weights where the rim is normally cleaned; the counterweight is pressed onto the rim surface in a visible area


► 5.2.5 - SPLIT FUNCTION (HIDDEN ADHESIVE WEIGHTS)


The SPLIT function is used to position the adhesive weights behind the wheel spokes so that they are not visible. This function should be used in ALU mode where the adhesive weight is applied on the outside. Input the wheel dimensions and do a spin.






• Turn the wheel to the outside unbalance correction position as indicated by the machine





• Position one spoke at 12 o'clock (e.g. 1) and press 



• Following the rotation direction indicated on the display, position spoke 2 at 12 o'clock and press 



• Position the wheel as indicated by the LEDs. The unbalance is indicated on the right-hand display



• Repeat the operation for the other spoke



• When the OPPOSITE POSITION function is enabled (see relative paragraph) the correction position at 6 o'clock is also indicated, so that the operator can easily insert the correction weight by pressing it downward.


To return to normal unbalance display, press any button.



NOTE: The distance between the spokes must be at least 18° and at most 120° (if not, the errors 24, 25 or 26 appear). Spokes with irregular or inconstant angles can be compensated.

► 5.2.6 - UNBALANCE OPTIMIZATION


- This function serves to reduce the amount of weight to be added in order to balance the wheel
- It is suitable for static unbalance exceeding 30 g.
- It improves the residual eccentricity of the tyre.



This operation is required if no unbalance has been measured previously; otherwise go to the next step

- Mark with chalk a reference point on the adapter and rim
- With the aid of a tyre changer, turn the rim on the tyre by 180°
- Refit the wheel with the reference mark coinciding between rim and adapter

- RH display: percentage reduction
- LH display: actual static unbalance which can be reduced by matching




- Mark the two positions of the rim and tyre, and turn the rim on the tyre until the positions correspond in order to obtain the optimization results shown on the display.



CANCEL OPTIMISATION IN ANY PHASE.

► 5.2.7 - AUTOMATIC MINIMIZATION OF STATIC UNBALANCE



This program is designed to improve the quality of balancing without any mental effort or loss of time by the operator. In fact by using the normal commercially available weights, with pitch of 5 in every 5 g, and by applying the two counterweights which a conventional wheel balancer rounds to the nearest value, there could be a residual static unbalance of up to 4 g. The damage of such approximation is emphasized by the fact that static unbalance is cause of most of disturbances on the vehicle. This new function, resident in the machine, automatically indicates the optimum entity of the weights to be applied by approximating them in an "intelligent" way according to their position in order to minimize residual static unbalance.

6 - SET UP

▶ 6.1 - MENU

↑	↕	OPT.		ENTER	See chapter on unbalance optimisation					
↓	↕	-d-		ENTER	-d-	00	↕	ENTER	diameter unit of measure mm/inch	ENTER
	↕	-b-		ENTER	-b-	00	↕	ENTER	width unit of measure mm/inch	ENTER
	↕	S.P.		ENTER	S.P.	OFF	↕	ENTER	start from guard closing	ENTER
	↕	APP.	R.	ENTER	APP.	5	↕	ENTER	approximates 1-5g 0,1-0,25oz	ENTER
	↕	APP.	C.	ENTER	APP.	50	↕	ENTER	approximates 10-50 g 0,25-10oz	ENTER
	↕	bIP		ENTER	bIP	On	↕	ENTER	acoustic signal activation on/off	ENTER
	↕	O.P.		ENTER	O.P.	On	↕	ENTER	Opposite position activation on/off	ENTER
	↕	SLP.		ENTER	SLP.	OFF	↕	ENTER	Static always present activation on/off	ENTER
	↕	SET	UP	ENTER						
↑	↕	dI R	On.	ENTER						
↓	↕	CAL.		ENTER						
	↕	Min.		ENTER	Min.	2	↕	ENTER	screen-saver duration (in minutes)	ENTER
	↕	CAL.	-d-	ENTER					Calibration of automatic RIM DISTANCE gauge	
	↕	CAL.	-d-	ENTER					Calibration of automatic DIAMETER gauge	

STOP RETURN TO MEASUREMENT SCREEN

6.2 - AUTOMATIC GAUGES CALIBRATION


▶ 6.2.1 - RIM DISTANCE GAUGE

CAL. -d-




r.P. []

- Leave the distance gauge in rest position and press



F.P. []

- Pull out the gauge up to the adapter flange and press



000 000

- **CORRECT CALIBRATION**
Return the gauge to rest position.
The wheel balancer is ready for operation.



N.B.: In the event of errors or faulty operation, the writing "r.P.": appears on the display: shift the gauge to the rest position and repeat the calibration operation exactly as described above. If the error persists, contact the Technical Service Department. In the event of incorrect input in the rim

distance gauge calibration function, press to cancel it.

▶ 6.2.2 - DIAMETER GAUGE

CAL. -d-




CAL. F.P.



- Place the round part of the gauge terminal on the flange as shown in the figure and press

352 0

- The number $352 \pm 3^\circ$ appears on the left display.



- Turn the gauge downward position the round part of the gauge terminal at 40 mm (radial distance) from the flange as indicated in the figure; alternatively use one of the cones provided as shown in the images

274 0

- The number $274 \pm 3^\circ$ should appear on the left display. The calibration is already correct.
- If not, press the button holding the gauge still at 40 mm: the number 274 appears on the left display.
- Return the gauge to rest position.

► **6.3 - BALANCING MACHINE CALIBRATION**

To calibrate the machine, operate as follows:

- Fit a medium-sized wheel with steel rim on the shaft. Example: 6" x 15" ($\pm 1"$) best with less than 20 g unbalance
- Take the exact measurements of the wheel mounted as described in *DATA SETTING*.



PRESETTING OF INCORRECT DIMENSIONS WOULD MEAN THAT THE MACHINE IS NOT CORRECTLY CALIBRATED, THEREFORE ALL SUBSEQUENT MEASUREMENTS WILL BE INCORRECT UNTIL A NEW SELF-CALIBRATION IS PERFORMED WITH THE CORRECT DIMENSIONS!

CAL.



StA rt

- Perform a manual spin under normal conditions



Add. 60

- Add a sample weight on the outside in any angular position.
Sample weight: 60 g. (2.00 .oz) for car
300 g. (10.0 .oz) for truck



60 Add.

- Shift the sample weight from the outside to the inside keeping the same angular position.



12

- Turn the wheel until the sample weight is in the 12 o'clock position



CAL.

- END OF CALIBRATION



- CANCELS CALIBRATION IN ANY PHASE.

7 - ERRORS

During machine operation, various causes of faulty operation could occur. If detected by the microprocessor, they appear on the display as follows:

Err. -5-

	ERRORS CAUSES	CONTROLS
	Black	The wheel balancer does not turn on.
	Err. 1	No rotation signal.
	Err. 2	Too low speed during measurement. During the unbalance measurement revolutions, the wheel speed has fallen to below 42 rpm.
	Err. 3	Too high unbalance.
	Err. 4	Rotation in opposite direction. After pressing [START], the wheel starts turning in the opposite direction (anticlockwise).
	Err. 5	Guard open The [START] pushbutton was pressed without first closing the guard.
	Err. 7 / Err. 8 / Err. 9	NOVRAM parameter read error
	Err. 11	Too high speed error. The average spinning speed is more than 240 rpm.
	Err. 14/ Err. 15/ Err. 16/ Err. 17/ Err. 18/ Err. 19	Unbalance measurement error.
	Err. 20	Wheel at standstill. The wheel is at a standstill for more than one second after START.
	Err. 21	Motor on for more than 15 seconds.
	Err. 22	Maximum number of spins possible for the unbalance measurement has been exceeded.
	Err. 24	Distance between the spokes smaller than 18 degrees.

Err. 25	Distance between the spokes greater than 120 degree	<ol style="list-style-type: none"> 1. The minimum distance between the spokes where to split the unbalance must be less than 120 degrees 2. Repeat the SPLIT function increasing the distance between the spokes.
Err. 26	First spoke too far from the unbalance	<ol style="list-style-type: none"> 1. The maximum distance between the unbalance position and the spoke must be less than 120 degrees. 2. Repeat the split function increasing the distance between the spoke and the unbalance.

► **7.1 - INCONSISTENT UNBALANCE READINGS**

Sometimes after balancing a wheel and removing it from the balancing machine, it is found that, mounting it on the machine again, the wheel is not balanced.

This does not depend on incorrect indication of the machine, but only on faulty mounting of the wheel on the adapter, i.e. in the two mountings the wheel has assumed a different position with respect to the balancing machine shaft centre line. If the wheel has been mounted on the adapter with screws, it could be possible that the screws have not been correctly tightened, i.e. crosswise one by one, or else (as often occurs) holes have been drilled on the wheel with too wide tolerances. Small errors, up to 10 grams (0.4 oz) are to be considered normal in wheels locked by a cone; the error is normally greater for wheels fastened with screws.

If, after balancing, the wheel is found to be still out-of-balance when refitted on the vehicle, this could be due to unbalance of the car brake drum or very often due to the holes for the screws on the rim and drum sometimes drilled with too wide tolerances.

In such case a readjustment could be advisable using the balancing machine with the wheel mounted on the car.

8 - ROUTINE MAINTENANCE (see exploded drawings) (for non specialized personnel only)

Always disconnect the machine from the mains before carrying out any operation.


► **8.1 - TO REPLACE THE DRIVING PULLEY**

The drive pulley is guaranteed by the manufacturer for approximately 20000 runs.

A spare pulley is found inside the base (see photograph).

If necessary, to replace the pulley, proceed as follows:

- Remove the head and the weight holder shelf, taking care not to damage the electric wires
- Remove the retaining screw on the pulley in order to replace it



► **8.2 - TO REPLACE THE BRAKE PAD**

Back-off the two screws fastening the worn brake pad to the motor mounting brake. Securely fix the new brake pad by tightening the screws.

► **8.3 - TO REPLACE THE FUSES**


Remove the weight holder shelf to gain access to the power supply board where the fuses are located. If fuses require replacement, use ones of the same current rating. If the fault persists, contact Technical Service.

► **8.4 - MAINTENANCE OF THE PNEUMATIC CIRCUIT**

It is important to periodically clean the compressed air filter.



N.B.: DRAIN FREQUENTLY ANY CONDENSATE BUILT UP IN THE FILTER BOWL VIA RELATIVE VALVE.
NONE OF THE OTHER MACHINE PARTS REQUIRE MAINTENANCE.



**CONTENT**

1 - TO CHANGE SUPPLY VOLTAGE	3
2 - INITIALIZATION OF BOARD	3
3 - TO ENABLE THE GAUGES	3
4 - SELF-DIAGNOSTICS	3
5 - DISTANCE SENSOR ADJUSTMENT	4
6 - DIAMETER SENSOR ADJUSTMENT	4
7 - PHASE GENERATOR REPLACEMENT	4
8 - POWER REPLACEMENT	6
9 - PIEZO SENSOR ASSEMBLY	5
10 - TROUBLE SHOOTING LOGIC SEQUENCE	6
11 - MANUAL DIMENSION PRESETTING (Use only in particular cases or for test)	7
11.1 - STEEL WHEEL RIMS (use for setting dimensions in AUTOCALIBRATION)	7
11.2 - ALUS RIMS	7
11.2.1 - ALUS VARIANT WITH INSIDE CLAMP WEIGHT	8
12 - FUNCTIONING AND ACCURACY TEST	9

1 - TO CHANGE SUPPLY VOLTAGE



The machine can run on 115 V - 50/60 Hz or 230 V - 50/60Hz.

To change the supply voltage, proceed as follows:

1. Replace the motor
2. Replace the entire power board
3. Replace the solenoid valves

2 - INITIALIZATION OF BOARD

If a board has never been calibrated, proceed as follows:

- switch on the machine keeping  pressed.
- the wording "Init ?" appears.
- press  to confirm.



N.B. Such operation causes the loss of any calibration or presetting carried out previously.

- Calibrate the machine again according to requirements.

3 - TO ENABLE THE GAUGES

If a board malfunctions or is replaced, the presence of the gauges must be selected as follows:

[MENU]	The word [Opt.] appears
[▼]	The word [Setup] appears
[ENTER]	The word [diAgn.] appears
[MENU]+[STOP]+[MENU]	press in sequence and within 5 seconds from when has been pressed [MENU]
[▼]	The words [Lan] [ci] appear
[ENTER]	The word [Cad] appears - diameter and distance gauge
[ENTER]	The words [Cad] [On] appear; always select ON using buttons [▼] [▲]
[STOP]	Confirm
	cancel enabling in any phase.

4 - SELF-DIAGNOSTICS

Should the machine malfunction, check the SELF-DIAGNOSTIC program before physically operating on the machine.

[MENU]	Press until [Setup] appears
[ENTER]	The word [diAgn.] appears; all the LEDs and the displays should light up simultaneously
[ENTER] Checking encoder	The words [Pos.] [7] appear; On the right-hand display the current position of the wheel is indicated with a number from 0 to 255. Turning the wheel in the direction of rotation, the number displayed should increase. Turning the wheel in the opposite direction of rotation the number displayed should decrease. With one full turn of the wheel the number 0 should appear only once.
[ENTER]	The words [Inc] [359] appear → Control parameter after calibration
[ENTER]	The words [r.1] [204] appear → Control parameter for technical service
[ENTER]	The words [r.2] [200] appear → Control parameter for technical service
[ENTER] Checking sensor dist.	The words [diS] [100] appear → Displays the DISTANCE sensor value when moving the gauge
[ENTER] Checking sensor diam.	The words [diA] [200] appear → Displays the DIAMETER sensor value when moving the gauge
[ENTER]	The words [diA] [Gn.] appear → End of self-diagnostics
[STOP]	Cancel self-diagnostics in any phase



5 - DISTANCE SENSOR ADJUSTMENT

This is necessary if there are irregularities in the value read during the SELF-DIAGNOSTIC measurements.


- Remove the weight shelf and refit the tip on the gauge rod.
- Back-off the screws fastening the pulley on the potentiometer shaft.
- Select on the FUNCTIONS MENU CONTROL OF THE FUNCTIONS MENU → SET UP → SELF-DIAGNOSTICS
- Scroll until the wording [dis.] appears on the left display while a number appears on the right display, which varies when the distance gauge is moved and represents a reference for calibrating the potentiometer.
- With the gauge fully retracted, turn the potentiometer shaft keeping the pulley still until a number between 0 and 5 is read.
- Retighten the screws to secure the pulley on the shaft.
- Carry out the DISTANCE GAUGE SET UP

6 - DIAMETER SENSOR ADJUSTMENT

This is necessary if there are irregularities in the value read during the SELF-DIAGNOSTIC measurements


- After DISTANCE SENSOR ADJUSTMENT press  ENTER
- The wording [dia] appears on the left display, a number appears on the right display, which varies when the gauge is turned and represents a reference for calibrating the potentiometer.
- Pull out the gauge so that its end touches the edge of the adapter flange
- Turn the potentiometer shaft supporting the pulley until reading a number between 0 and 5
- Fit the weight tray; check that a number between 10 and 50 appears with the gauge in rest position. If not, adjust the value without the weight tray
- Tighten the screws to secure the pulley to the shaft
- Carry out the DIAMETER GAUGE SET UP
- After the adjustments, calibrate the automatic gauges ( *Instructions for use*).

7 - PHASE GENERATOR REPLACEMENT



- Release the anti-rotation spring
- Disconnect the flat cable connector
- Remove the phase generator by unscrewing the hexagonal screw clockwise (opposite to standard)
- Replace the phase generator screwing it in anticlockwise
- Attach the connector restoring the original wiring and leave the flat cable with a wide curve to prevent any tension on it
- Properly refit the spring.

8 - POWER REPLACEMENT



9 - PIEZO SENSOR ASSEMBLY




FOR CORRECT OPERATION, INSULATION OF THE PIEZO CRYSTALS SHOULD BE GREATER THAN 200 MOHM (TYPICAL 2000 MOHM)

Problems of excessive compensation and out-of-phase sometimes depend on a fault in the piezo measurers. To replace them, proceed as follows:

1. Remove the weight shelf.
2. Remove nuts 1 and 2 with relative cup springs and washers.
3. Back-off screws 3, 4, 6 and 5 then disassemble the various parts.
4. Reassemble the various parts without tightening the nuts being careful to follow the correct sequence.




Mount the piezo units in accordance with the position of the coloured wires shown in the drawing.





5. Keeping the spindle perfectly aligned, tighten the nuts 5 and 6 with a spanner, and nuts 3 and 4 by hand (by half a turn with the spanner if necessary).
6. Refit the washers, cup springs and nuts 1 and 2. Tighten the nuts fully in order to fully regain the elasticity of the cup springs, then loosen them by half a turn. This will automatically ensure correct preloading on the piezo (a torque wrench can be used set to 40 N.m).
7. Again carry out the calibration.

10 - TROUBLE SHOOTING LOGIC SEQUENCE



11 - MANUAL DIMENSION PRESETTING (Use only in particular cases or for test)

▶ 11.1 - STEEL WHEEL RIMS (use for setting dimensions in *AUTOCALIBRATION*)





Press one of the two buttons to access manual setting:

- Set the nominal width, normally indicated on the rim, or measure the width "b" using the caliper gauge supplied. Press **abd** for more than 2 seconds

- Set the distance "a" between the inside of the wheel and the machine
Press **abd**

- Set the nominal diameter "d" indicated on the tyre. Press **abd**

▶ 11.2 - ALUS RIMS





Press one of the two buttons for more than 2 seconds



Note: not setting dE as it is automatic, $dE = dI - 1"$.

▶ 11.2.1 - ALUS VARIANT WITH INSIDE CLAMP WEIGHT



Press one of the two buttons for more than 2 seconds



Note: not setting dE as it is automatic, $dE = dI - 2''$.

12 - FUNCTIONING AND ACCURACY TEST

If faults or inaccuracies are encountered which are not readily identified, it may be useful to perform the function and precision check.

PRELIMINARY CONTROLS

- Carefully clean the flange and cones
- Spring cover sliding
- Shaft terminal locking

ENCODER COUNT TEST

Press:

[MENU]	
[▼]	The word [Setup] appears
[ENTER]	The word [diAgn.] appears
[ENTER]	Confirm

After a brief LED and display test, the wheel position appears on the right-hand display, which must vary in the range 0+255 in a full turn.

CHECKING MACHINE OSCILLATION

After running autocalibration, press [STOP] to return to the standard measuring frame.

Without locking the wheel, measure the machine oscillation as follows:

[MENU]	
[▼]	The word [Setup] appears
[ENTER]	The word [diAgn.] appears
[MENU]+[STOP]+[MENU]	Press in sequence in maximum 5 sec.
	The words [Lan] [ci] appear
[ENTER]	Confirm.
	The letters [t.L.] [10] appear
[START]	Run a cycle of 10 spins with automatic calculation and display of the maximum oscillation (max. permitted +/- 2 g), i.e. 4 grams on the indicator
[ENTER]	The following appears [Inj] [~70] (truck)
[ENTER]	The following appears [End] [~60] (truck)
[ENTER]	End of test.
[STOP]	Return to the standard measuring frame.

If you wish to run more than 10 automatic spins, when [t.L.] [10] appears press the buttons [▲] / [▼] to select the desired number in the range 5%999.

CHECKING MACHINE CALIBRATION

With the wheel perfectly balanced, apply 60 g first on the outside and then on the inside.

The wheel balancer must measure:

Fl=0	FE=60	Weight F.E. = position = 6 o'clock
Fl=60	FE=0	Weight F.I. = position = 6 o'clock


Permitted tolerance on 60 g. = 5%.

Tolerance on residue = max. 5 g.

CHECKING THE ADAPTER


When the wheel is perfectly balanced, tip over by 180° and measure the unbalanced values.

For this test, it is advisable to use a new wheel of good quality. The error due to tilting should be less than 6 g. (3 g actual); replace the centring cones if necessary.




C212 (B)

E-0693-C212-GB.PDF
07-2009




D0693-1	0693-1	1	MANDRINO+MOTORE+DATORE DI FASE+ TRASDUTTORI PIEZO	SHAFT ASSEMBLY+MOTOR+POSITION PICK-UP+ PIEZO TRANSDUCER
D0693-2-3-4	0693-2-3-4	2-3-4	BASAMENTO+CALIBRO DISTANZA+POTENZA	CASING+DISTANCE GAUGE+POWER UNIT
D0696-5	0696-5	5	PROTEZIONE RUOTA	WHEEL GUARD
D0693-7	0693-7	7	LIFT	LIFT

D0693-1	0693-1	1	DORN+MOTOR+PHASEGEBER+ PIEZOGEBER	BROCHE+MOTEUR+DONNEUR DE PHASE+TRANSDUCTERS PIEZO	MANDRIL+MOTOR+CAPTADOR DE FASE+TRANSDUCTORES PIEZOELECTRICOS
D0693-2-3-4	0693-2-3-4	2-3-4	SOCKEL+ABSTAND MESSLEHRE+ NETZEINHEIT	BASE+CALIBRE DISTANCE+ PUISSANCE	BASE+CALIBRE DISTANCIA + POTENCIA
D0696-5	0696-5	5	RADSCHUTZVERKLEIDUNG	PROTECTION ROUE	PROTECCION RUEDA
D0693-7	0693-7	7	LIFT	LIFT	LIFT




N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION
1	4RFM86822	COMPLETE SHAFT	10	182185730	SPRING			
2	42FM82433	THREADED END	11	4RFM86828	PIEZO ASSEMBLY			
3	4RSD86802	COMPL. POSITION PICK-UP						
4	42FB37113	COMPLETE BRAKE PAD						
5	161035030	PNEUMATIC CYLINDER						
7	07FG33406	DRIVING PULLEY						
8	5RFG86832	CAPACITOR+MOTOR 230V						
8	5RFG86833	CAPACITOR+MOTOR 115V						
9	568001058	CAPACITOR 230V						
9	568003558	CAPACITOR 115V						


2-3-4




N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION
1	14FB81341	COVER WITH WEIGHT TRAY	9	46FC76792	FIXED RETAINER	19	528003246	CABLE CIRCLIP
2	14FB80487	FRAME	10	46FB46703	FIXING KIT	21	86PR86283	COMPLETE PANEL
3	05PR81025	CONTROL PANEL	11	42FB81344	BASE			
4	67D71370B	COMPUTER BOARD	12	46FB74884	WHEEL KIT			
5	14FB80488	HEADSTOCK	13	46FC84027	COMPL. DISTANCE GAUGE			
6	67M80813A	POWER SUPPLY BOARD 230V	14	46FC80526	GAUGE BRACKET			
6	67M80813B	POWER SUPPLY BOARD 116V	15	86SB78574	DIST. GAUGE+POTENTIOM.			
7	568001058	CAPACITOR 230V	16	86SB67291	DIAM. GAUGE+POTENTIOM.			
7	568003558	CAPACITOR 116V	17	511242101	PLATFORM SWITCH			
8	42FB84036	BASE PLATE	18	46FB84028	TRUCK PIN KIT			



N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION
1	46FW84146	COMPL. WHEEL GUARD						
2	14FW31322	SIDE COVER						
3	14FW38518	UPPER BAND						
4	86SB86750	CABLE WITH MICROSWITCH						
5	14FW33850	UPPER COVER						
6	42FW38517	TUBE CHASSIS						
7	18FW31346	AIR SPRING						
8	42FW33446	SUPPORT						



N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION	N.	CODE	DESCRIPTION
1	16400014	MICRO REGULATOR						
2	46FL84143	COMPLETE LIFT						
3	161900110	CYLINDER TORPLESS						
4	42FL84144	WHEEL LIFT						
5	42FL70056	TROLLEY FOR LIFT						
6	020620102	BEARING						
7	46FB74829	PEDAL ASSEMBLY						
8	16SP33941	ELECTROVALVE 230V						
8	16SP33942	ELECTROVALVE 116V						
9	164000006	FILTER						



Truck wheel balancer equipment Ø 40



Cone adaptor

UC215 HW (C)



IV - V CONE Centring Kit

OPTIONS for
UC215 HW (C)



SR215/2 Centring Kit

OPTIONS for
UC215 HW (C)



SR3 adaptor

OPTIONS for
UC215 HW (C)



TRILEX / DAYTON Kit

OPTIONS for
UC215 HW (C)



Quick locking ring kit 40 x 4 with GP ring nut
G40 steel wing nut

OPTIONS for
UC215 HW (C)



Universal quick adaptor

UH20/2



Universal adaptors for driving wheels

RM20/15


Ø 40

Ø 40



UC215 HW (C) cone adaptor

UC215HW (C)
with ring nut
GMM40
41FF59368



GENERAL FEATURES:


- For wheel balancers with cone adaptor body incorporated in the machine shaft, complete with preloaded spring.
- With cones and shaft in hardened steel
- For locking motor vehicle/pickup truck wheels with central hole
- For wheel balancers with guard the ring nut GMM40 can be used without the handwheel

ITEM	CODE	DESCRIPTION	DATA
1	42FM62433	threaded end-piece	L = 205
2	325047011	knurled washer	Ø 10
3	312120137	screw	TCEI M10x160 UNI 5931
4	114008002	allen wrench	8 mm
5	40FF88351	A1 cone	Range Ø 45 + 69
6	40FF43716	A2 cone	Range Ø 60 + 81
7	40FF43716	A3 cone	Range Ø 79 + 110
9	40FF52417	VL/2 cone	Ø 97+170 (Ø 97+180 with GG)
10	40FF43745	G40 spacer disc	
11	312120119	screw	TCEI M10x20 UNI5931
12	40FF79260	polyurethane ring	
GG	940010105	GG ring - In optional IV-V cone kit	



MOUNTINGS

STANDARD PICKUP TRUCKS




OPTION FOR WHEELS WITH CENTRAL HOLE
170+180 Ø.

Mounting the GG ring (in optional IV-V CONE KIT) on the disc (10), pickup truck wheels up to 180 Ø central hole can be locked.

Models:


- Pick Up - FORD
- F250 super cab XLT
- F250 crew cab XLT
- F350 crew cab LARIAT
- F350 crew cab DUALIE
- F450
- MERCEDES
- Sprinter New series



AUTO


It is recommended to use the adaptor with centering from the inside.

- In sequence mount the suitable cone with the taper to the outside, the wheel, the collar and the ring nut.



GMM40
41FF59322

A	40FF61334
B	40FF51315
C	40FF79260
D	41FF83146
E	312120067
F	321232006
G	218295313
H	217295353
J	325035006
L	312120073




Ø 40




OPTIONS - UC215 HW (C) cone adaptor

IV-V CONE
Centering
Kit
41FF43821



GENERAL CHARACTERISTICS:
- Suitable for all truck wheels
- For locking wheels with central hole


ITEM	CODE	DESCRIPTION	DATA
11	312120119	screw	TCEI M10x20 UNI 5931
12	326036011	flat washer	Ø 11/30/2,5 UNI 6593
13	40FF43747	V cone	Ø 281
14	40FF43748	IV cone	Ø 202/221
15	940010105	GG ring	

OPTION			
14a	40FF60653	special cone IV 8,5"	Ø 202/214/215,9 



MOUNTINGS


Ø 281
(central hole)



Ø 221 (202)
(central hole)

with option 14a


Ø 202
Ø 214
Ø 215,9
(central hole)



Ø 40



T NS - UC215 HW (C) cone adaptor



SR215 2
center n
t
41FF6 8 9


GENERAL FEATURES:

- Standard tire UC215HW
- Standard tire UC215HW
- Accurate centring and field of view (18) and a point of correction on the outer and inner centring flange (16) The field of view (19) or (21) is not affected by the centring flange (16) The field of view (19) or (21) is not affected by the centring flange (16)

ITEM	CODE	DESCRIPTION	DATA
16	40FF67860	centring ange	
17	312120119	screw	TCEI M10x20 UNI5931 (2 pieces)
18	40FF67883	stud bolt	(5 pieces)
19	40FF67881	6-armed spider	10 holes on Ø 226 10 holes on Ø 285,75 10 holes on Ø 336
20	40FF67916	locking	(5 pieces)
21	40FF67882	4-armed spider	8 holes on Ø 276 8 holes on Ø 285,75




MOUNTINGS SR215/2




NOTE: The flange (16) can also be fitted directly to the rear anchor castor to the interposed castor (10)


Ø 40  T NS - UC215 HW (C) cone adaptor

SR3
A A T R
41FF66114



MAIN FEATURES:
 - Standard taper
 - Centering disk (28) in the center of the wheel
 - 3-arm spider (25) in the center of the wheel
 - 3 studs (26) and 3 nuts (27) in the center of the wheel
 - Taper in the center of the wheel

ITEM	CODE	DESCRIPTION	DATA
25	40FF66115	3-arm spider	 <p>Main car models</p> <ul style="list-style-type: none"> - FIAT DAILY - MITSUBISHI CANTER T35 - OPEL BEDFORD - FORD TRANSIT FT 130-190 100L - TOYOTA Dyna 150 - MERCEDES LLKW serie 400, 500, 600, 700, T1/T2 - VOLKSWAGEN LLKW LT 35-55 / L80 - MITSUBISHI CANTER T75 - Light trucks in general
26	40FF66117	Stud	(3 pieces)
27	40FF66116	Nut	(3 pieces)
28	40FF66118	Centering disk	(Ø 161 mm)



T NS - UC215 HW (C) cone adaptor




Ø 40

Ø 40  **T NS - UC215 HW (C) cone adaptor**

ATTN
20 24
(USA)
94FF3 124


ATTN
20 24
(USA)
94FF3 124

TRLE
20 22.5
(EUR E)
94FF3 122



- GENERAL FEATURES:**
- suitable for one-piece rims
 - the adaptor is centred and locked on the spindle using a cone or in W standard equipment
 - the rim is centred on the conical sectors and fixed with the brackets provided

MOUNTINGS






UC
L C NGRNG
T40 4
t GL
r n n t

41FF83154

GENERAL FEATURES:


- For locking motor vehicle wheels
- see the standard cone equipment as recommended in the W cone flange brochure




ITEM	CODE	DESCRIPTION	DATA
21	40FF51315	collar	Ø 130 outside
22	40FF61334	pressure ring	Ø 80 outside
23	40FF79256	RL collar for light alloy wheels	Ø 208 outside
24	40FF79258	Polyurethane ring for RL collar	
25	40FF79260	Polyurethane ring for collar	
	41FF79259	Complete collar	
	41FF79255	Complete RL collar	

GL
quick
locking ring

41FF83146




ITEM	CODE
A	40FF79990
B	40FF79984
C	40FF79989
D	40FF79991
E	18FW80018
F	314932039



G40
steel
wing nut


40FF43726



Ø 40



Universal quick adaptor UH20/2



UH20/2



complete adaptor for wheel balancers with manual or pneumatic locking

41FF42048

GENERAL FEATURING :

- for wheels with or without central hole.
- The additional cone 11 (CEMB patent), in most cases, allows to center the wheel on the central hole, thus improving balancing accuracy.

Fit for any motor-vehicle wheels with 3, 4 or 5 holes on Ø 95 up to 210 mm.




ITEM	CODE	Q.ty	DESCRIPTION	DATA
①	321232008	2	nut	M8 UNI 5588
②	325035008	2	flat washer	Ø 6,4 x 17
③	40FF33438	1	adaptor body	
④	40FF33439	1	guide disc	
⑤	40FF33440	5	complete stud bracket	
⑥	40FF33441	4	gauged screw	burnished
⑥*	40FF33443	1	gauged screw	tropicalized
⑦	940052253	1	gauge	
⑧	115006002	1	t-wrench	hexagon 6
⑨	40FF33442	5	special nut	conic 60° / spherical radius 10
⑩	112019220	1	socket spanner	hexagon 19/22
⑪	40FF42165	1	pre-centering cone	Ø 52 + 72,5
⑫	41FF38501	1	kit of 5 special long nuts	conic 60° / spherical radius 8 (for Peugeot 406)



FITTING





BASIC SETTING FOR PATTERN MODIFICATION




1) Change the adaptor pattern (3;4;5) according to any requirements.

N.B. :


do not lock studs (5) leaving screws (6) and (6*) loosen, to enable the operation at point 3).



2) Measure the distance between two of wheel holes with the gauge (7).



3) Line the axles of two studs to the gauge prod.



4) Lock the screws(6) and(6*).

5) Fit the wheel.

N.B.:

The use of cone (11) generally improves the wheel centering accuracy.

6) Lock the nuts by hand (9).

7) Lock the nuts with the socket spanner (10), not too tight.


Ø 40



Adaptor for motorcycle wheels RM20/15

RM 20/15
Ø 15
41FF49115

Filling with elastic



GENERAL FEATURES :
• It centers all wheels with central through hole.

ITEM	CODE	Qty	DESCRIPTION	ITEM	CODE	Qty	DESCRIPTION
1	40FF49312	1	adaptor body	16	40FF46721	1	shaft Ø 15 L=270 (only for 42" wheel guard) Harley Davidson
2	940013571	1	shaft Ø 15 L=251	17	424116877	2	cone Ø 15-35
3	40FF29927	2	cone C1 Ø 15-25	18	42FF46162	1	elastic (17") Ø 6 L=680
4	940013796	1	elastic Ø 6 L=580	19	41FF51299	1	COMPLETE KIT OF CENTERING BUSHES
5	40FF29950	1	locking Ø 15		40FF31651	2	B1 L=30 Ø 28 Yamaha
6	40FF29932	1	spacer Ø 15 L=40		40FF38838	2	B2 L=30 Ø 25 Kawasaki
7	40FF29931	1	spacer Ø 15 L=20		40FF38837	2	B3 L=30 Ø 22 Yamaha, Honda, Aprilia, Gilera, Kawasaki, Suzuki
8	325035014	1	washer Ø 15 x 28		40FF38836	2	B4 L=30 Ø 20 Yamaha, Honda, Aprilia, BMW, Triumph, Kawasaki, Suzuki, Laverda, Moto Guzzi, KTM
9	40FF49313	4	movable pin		40FF38835	2	B5 L=25 Ø 17 Yamaha, Suzuki, KTM
10	424115806	2	plate		40FF38834	2	B6 L=20 Ø 16 Moto Guzzi
11	325035013	2	washer Ø 13 x 24 UNI 6592		40FF38833	2	B7 L=20 Ø 15 Yamaha, Honda, Aprilia, Gilera, Kawasaki, Suzuki
12	321232012	2	nut M12 UNI 5588		40FF49378	2	B8 L=25 Ø 19,05 Harley Davidson
13	315231064	2	screw TS M6x25 UNI 6109				
14	325035006	2	washer Ø 6,4x12,5 UNI 6592				
15	321232006	2	nut M6 UNI 5588				

Adaptor for motorcycle RM20/12



Ø 40