Wheel Mounting Procedures

Remove rust and dirt : Inspect all components : Snug wheel nuts : Torque to specification

Remove rust and dirt from all mating surfaces

Since 1951



1-800-525-8888