

# C SERIES HOSETRACT INDUSTRIES REPLACEMENT PARTS LIST

07/01/08

WHEN ORDERING ANY OF THE PARTS LISTED BELOW, BE SURE TO INCLUDE THE MODEL NUMBER AND SERIAL NUMBER OF REEL.

MODEL NO	A

#### REVERSE

SIDE LETTER CODE	DESCRIPTION  BASE ASSEM	PART NUMBER				REQ'
A			**	1256A		1
В	GUIDE ARM ASSEM			1262A		1
C	SPOOL ASSEM			1330A		1
D	SPRINGCASE COVER			1259		1
E	INLET SHAFT		1122	3190	1123	1
F	SWIVEL ASSEM	1245A	1165A	1413A	1238A	1
G	DRIVE SPRING		3303A	3296A	3297A	1
Н	LATCH ARBOR			3128		1
I	LATCH PAWL			1716A		1
J	OBSOLETE (PAWL RETAINER)	50000000		1133		0
K	RETAINER RING .050 X 1 1/4			1125		2
L	U-BOLT			11492		2
M	SET SCREW 3/8-16 X 3/8			11273		1
N	SLOT HD SCREW 10-32 X 3/8			11362		4
0	NYLON LOCK NUT 10-32			11382		1
P	SELF LOCKING NUT 1/4-20			11412		8
Ô	HEX HEAD BOLT 1/4-20 X1/2		100 may	11422		4
R	GUIDE ROLLER ASSEM	www.co.co		1224A		1
S	STREET ELL			1458		1
T	SPRINGCASE WITH LATCH ITEM		400	1338A		1
U	LATCH SPRING			3134	1	1
V	GASKET			3137		1
W	SPRINGCASE STUD	_		31392		1
X	NYLON LOCK NUT 1/4-20			11402	consequium X	4
Y	SELF LOCKING NUT 10-32			11352		9
Z	PRESS SCREW 10-32X 5/8			11292		5
AA	PRESS SCREW 1/4-20X 3/4			11302		4

NOTE: DRIVE SPRING CAN BE SHIPPED TWO WAYS

- 1. SPRING ONLY ITEM G
- 2. SPRING COMPLETE IN CANISTER READY FOR ATTACHMENT TO REEL (EXTRA CHARGE) SPECIFY: IN CANISTER

TERMS: U.S. Currency Net 30 Days, F.O.B. Factory

## PROPER INSTALLATION WHEN INSTALLING REEL, RIDGID OR SOLID PIPE INLET HOOKUP

WILL VOID WARRANTY. BE SURE TO USE FLEXIBLE INLET TO SWIVEL.

#### HOSE INSTALLATION

WITH SPOOL DETENSIONED, INSERT HOSE THROUGH HOLE IN SPOOL AND ATTACH U-BOLT. BACKWIND HOSE COMPLETELY ONTO SPOOL, THEN ROTATE FORWARD TWO REVOLUTIONS (PRELOAD), LATCH AND ATTACH STOP!

#### HOSE STOPS

1/4 - 1234A 3/8 - 1233A 1/2 - 1232A

#### REEL TENSION

THE HOSETRACT REEL HAS A DECEIVINGLY SMOOTH,

BUT POWERFUL RETRACTION RATE. HOSE TENSION IS FACTORY SET, AND UNLESS A GROSS DECLINE IN TENSION IS NOTICED, NO FURTHER ADJUSTMENTS ARE NECESSARY. OVER TENSIONING CAN CAUSE SPRING DAMAGE, AND VOIDING OF THE WARRANTY. ALWAYS MAINTAIN HAND CONTROL OF THE HOSE UPON RETRIEVAL, ALLOWING HOSE TO RECOIL UNABATED AT A HIGH RATE OF SPEED CAN CAUSE PERSONAL, VEHICLE, OR REEL DAMAGE.

### OXYGEN-ACETYLENE INSTRUCTION INLET FITTINGS TO THREAD OXY-ACET HOSES ONTO HOSE REEL ARE INCLUDED WITH

EACH REEL.

WHEN INSTALLING ANY FITTINGS INTO THE OXY-ACET SWIVEL OR REEL, BE SURE THAT THE NOTCHED FITTING FOR THE GAS SIDE IS INSTALLED IN THE SAME NOTCHED MATING PART.

#### WARRANTY

HOSETRACT HOSE REELS AND HOSETRACT SWIVELS ARE WARRANTED TO THE ORIGINAL USER AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP UNDER NORMAL USE AND PROPER INSTALLATION FOR ONE YEAR AFTER DATE OF PURCHASE. ANY PART, EXCEPT NOTED EXCLUSIONS, SHIPPED PREPAID TO AN AUTHORIZED SERVICE OUTLET OR THE FACTORY, WHICH IS DETERMINED TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP, WILL BE REPAIRED OR REPLACED. COMPONENTS NOT MANUFACTURED BY HOSETRACT SUCH AS HOSE AND OPTIONAL SWIVEL CHOICES ARE EXCLUDED FROM HOSETRACT'S WARRANTY.

#### HOSETRACT INDUSTRIES, LTD.

MAILING: P.O. BOX 80008, FORT WAYNE, IN 46898 SHIPPING: 6433 DISCOUNT DR., FORT WAYNE, IN 46818 TELEPHONE (260) 489-8828 FAX (260) 489-6088

www.hosetract.com