

Models: VM6-1, VMP6-1, VMP6-1A, VM6-3

Capacity 6,000 lbs.

(Maximum 1,500 lbs. per adapter)

M
I
D
R
I
S
E

L
I
F
T
VM6-1 Shown


PARTS BREAKDOWN

IMPORTANT: When ordering parts always give exact model and power unit serial number. Model number is shown on nameplate attached to center member of superstructure. Serial number is located on side of power unit reservoir.

Complete information at right and keep in a safe place.

OWNER'S RECORD

PART OF LITERATURE PACKAGE LP30037



ITEM NO.	DESCRIPTION	PART NO.	ITEM NO.	CEMENT PARTS ONLY*		PART NO.
1 EWINO.		14404		DESCRIPTION		
2	Spirol Roll Pin	14599	33	Pin Weldment		FJ862
3	ALI Member Nameplate		34	Retainer		FJ863
	3/8" Shoulder Bolt	40170	35	Foot Warning Decal		NP253
4	1/2" Shoulder Bolt	40172	36	Locking Leg Decal		NP378
5	3/8" x 1" Whiz-Lock Bolt	40144	37	Adapter Name Plate		NP387
6	5/8" x 7" UNC Grade 8 HHCS	40358	38	Rotary Decal		NP412
7	5/8" Plastic Washer	40802	39	Locking Leg Warning Decal		NP461
8	1 15/16" x 1/8" dia. Hair Pin Cotter	41170	40	Jack Bar		FJ2277
9	1/8" x 1 1/4" Cotter Pin	41201	41	Sleeve		FJ2277-5
10	5/32" dia. x 3/8" Spirol Roll Pin	41605	42	230V Electric Power Unit (VM6)		P838
11	5/16" Narrow Rim Nylon Washer	41607	43	115V Electric Mobile Power Unit (VMP6)		P840
12	3/8" Narrow Rim Nylon Washer	41608	44	Air Power Unit (VMP6A)		P836
13	Machinery Bushing Washer	FJ2252-4	45	5/8" Concrete Anchor		FC5228
14	Wheel	FJ2271-1	46	3/32" Hog Ring		FJ671-6
15	Nut	FJ2298-8	47	Adapter Pin		FJ671-3
16	Arm Retainer	FJ2372	48	Low Step Adapter		FJ671-2
17	5/8"-18 Stover Lock Nut	FJ2375	49	High Step Adapter		FJ671-1
18	Swivel Arm Ass'y.	FJ2379	50	Swivel Arm / Adapter Base		*
19	Base Assembly	FJ2461	51	Adapter Swivel Pin		FJ79- 6
20	Right Rear Leg Weldment	FJ2395	52	Vertical Stand		FJ864
21	Front Leg Weldment	FJ2463	53	Portable Stand		FJ2410
22	Top Structure	FJ2397	54	3/8" Concrete Anchor		FJ5388-98
23	Locking Leg Weldment	FJ2398	55	Optional Cylinder Cover		FJ2354
24	Unlocking bar	FJ2399	56 Hose	Hose	VM6	FJ85
25	Pivot Bar Weldment	FJ2400		11000	VMP6, VMP6A	FJ851
26	Pedal Weldment	FJ2401	57	5/16" x 3/4" Bolt		40224
27	Actuator Arm Weldment	FJ2402	58	5/16" Lock Nut		40678
28	Left Rear Leg Weldment	FJ2415	59	Female Coupler Half (VMP6,VMP6A)		FJ850
29	Stop Weldment	FJ2417	60	P/U Wall Mount Bracket (VM6-3)		T120020
30	Release Spring	FJ2420	61	Power Unit Stand Cap		FJ2467
31	Cylinder Clip	FJ2293-1				
32	Hydraulic Cylinder	FJ860				

 $^{{}^{\}textstyle \star}{}$ Note: If adapter base needs replacing, it is more economical to replace the entire adapter.

 $^{^{\}star\star}$ Note: Not all VM6-1 parts are interchangeable with VM6.

Attention Installer:

Please return this booklet to literature package and give to lift owner/operator.

Trained Operators and Regular Maintenance Ensures
Satisfactory Performance of Your Rotary Lift.

Contact Your Nearest Authorized Rotary Parts Distributor for Genuine Rotary Replacement Parts. See Literature Package for Parts Breakdown.











World Headquarters:
ROTARY LIFT
A DOVER INDUSTRIES COMPANY
2700 Lanier Drive

Madison, IN 47250-1753 USA Phone toll-free: 1-800-445-5438 Phone: (812) 273-1622 Fax toll-free: 1-800-822-6502

Fax: (812) 273-6502
E-mail: userlink@rotarylift.com
Web site: www.rotarylift.com

For Canada: **DOVER CORP. (CANADA) LTD. ROTARY LIFT DIVISION**

130 Bridgeland Avenue Unit 210 Toronto, Ontario M6A 1Z4 Phone: (416) 256-4100 Fax: (416) 256-3924 For United Kingdom & Republic of Ireland: ROTARY LIFT (UK) LIMITED

Madison House 2 Park Road Dartford, Kent DA1 1SL

Phone: +44 (0) 1322 223323 Fax: +44 (0) 1322 222454 For Europe: ROTARY LIFT EUROPE Berlinger Ring 163 B D-64625 Bensheim

Phone: +49 (0) 6251 787037 Fax: +49 (0) 6251 787038