




Parts List For Bead Breaker 11070

BEAD BREAKER ASSEMBLY MODEL 11070



2324 Circuit Way, Brooksville, FL 34604
Phone (352) 799-1111 Toll Free (877)755-4263 Fax (352)799-1112
Email:sales@ameintl.net



MODEL 11070 Parts List

ITEM	PART #	Stock #	Description	Qty	ITEM	PART #	Stock #	Description	Qty
1	11070-001	71412321	BOLT	1	21	11070-021	71412268	TEETH, CLAMPING	1
2	11070-002	71412322	NUT	1	22	11070-022	71412269	TONGUE	1
3	11070-003	71411177	HANDLE	1	23	11070-023	71412270	SCREW	1
4	11070-004	71412323	BASE, CONNECTING ROD	1	24	11070-024	71412271	WASHER	1
5	11070-005	*	RING,SEAL	1	25	11070-025	71412331	SCREW	1
6	11070-006	*	RING,SEAL	1	26	11070-026	71411175	PLUG	1
7	11070-007	71412264	ROD CONNECTOR	1	27	11070-027	71411173	SPRING	1
8	11070-008	71412324	HOUSING,CLAMP CYL	1	28	11070-028	71412272	BALL, SEQUENCING	1
9	11070-009	71412265	SCREW	1	29	11070-029	76396884	O-RING	1
10	11070-010	71412325	ROD, CLAMP CYL	1	30	11070-030	71412332	WASHER	1
11	11070-011	71412266	SPRING	1	31	11070-031	71412333	SCREW	1
12	11070-012	71412326	HEAD, BREAKER CYL	1	32	11070-032	71412273	SPRING	1
13	11070-013	*	SEALS	2	33	11070-033	71412274	BALL	1
14	11070-014	71412327	ROD, BREAKER CYL	1	34	11070-034	71412334	NUT	1
15	11070-015	71412328	BODY	1	35	11070-035	71412275	SNAP RING	2
16	11070-016	71412329	SCREW	1	36	11070-036	*	SEAL	1
17	11070-017	71412267	JAW	1	37	11070-037	71412335	NUT	1
18	11070-018	71412330	PIN, JAW PIVOT	1	38	11070-038	71412276	SNAP RING	2
19	16060	71411176	COUPLER	1	39	11070-039	71412277	PIN, ROD CONNECTOR	1
20	11070-020	71411174	WASHER	1	40	11070-040	94396604	*SEAL KIT (INCL. 5,6,13,36)	1



2324 Circuit Way, Brooksville, FL 34604
 Phone (352) 799-1111 Toll Free (877)755-4263 Fax (352)799-1112
 Email:sales@ameintl.net