

## TIM-317-A Waste Oil Drain Illustrated Parts Breakdown

#	QTY	Description	Part No.
3	Not sold as a piece part.		
4	4	Casters (sold as pair)	TIM-317-4
5	4	Plain Washer	TIM-317-5
6	4	Acorn nut	TIM-317-6
7	2	Elbow	TIM-317-7
8	2	Nut	TIM-317-8
9	1	Tube with label	TIM-317-9
10	1	Double end adapter	TIM-317-10
11	1	3/4" Ball valve	TIM-317-11
12	1	Discharging hose	TIM-317-12
13	1	Chain	TIM-317-13
14	1	Pan head screw	TIM-317-14
15	1	Plug	TIM-317-15
16	2	O-ring 16 x 2.4 (sold as pair)	TIM-317-16
17	2	Screw w/ chamfered end	TIM-317-17
18	1	Screw	TIM-317-18
19	1	Hose clip	TIM-317-19
20	1	Handle	TIM-317-20
21	Not sold as a piece part.		
22	1	T-elbow adapter	TIM-317-22
23	1	Safety valve - 12 psi	TIM-317-23
24	1	Tool tray	TIM-317-24
25	1	Seat	TIM-317-25
26	1	Hand wheel	TIM-317-26
27	2	O-ring 32.92 x 3.53	TIM-317-27
28	1	O-ring 48.9 x 2.62	TIM-317-28
29	1	Spring	TIM-317-29
30	1	Nut	TIM-317-30
31	1	Adjusting steel tube	TIM-317-31
32	1	Ball valve	TIM-317-32
33	1	Bowl supporting tube	TIM-317-33
34	1	Set Screw	TIM-317-34
35	2	O-ring 32.9 x 2.62 (Sold as pair)	TIM-317-35
36	1	Rotor	TIM-317-36
37	1	Oil collecting bowl	TIM-317-37
38	1	Filtrating plank	TIM-317-38
39	1	Funnel extender	TIM-317-39
41	4	Spring Washer	TIM-317-41
42	1	Ring	TIM-317-42
43	1	Ball valve	TIM-317-43
44	1	Plug kit (includes #44 Drain Plug Nut and #45 O-ring 24x2.65)	TIM-317-PLUG
45			

