

CONTENTS

13 AIR SYSTEMS

Compressor Selection Guide _____	15
Building an Efficient Air System _____	16
Air Compressors & Dryers _____	17
Nitrogen Tire Filling Systems _____	32
Air Preparation Products _____	34
Air Hoses, Hose Reels & Hose Products _____	38
Air Line Couplers, Plugs & Accessories _____	42

51 AIR TOOLS

Impact Wrenches (CP) _____	53
RPG Air Tools _____	58
Sanders & Air Ratchets (CP) _____	62
Buffers, Grinders, Drills & Accessories (CP) _____	64
Impact Wrenches (IR) _____	68
Grinders, Buffers, Sanders & Drills (IR) _____	72
Cordless Tools (IR) _____	74
Air Tool Accessories (IR) _____	75
Work Stations _____	76

77 WHEEL SERVICE PRODUCTS

Impact Socket Sets _____	78
Individual Impact Sockets _____	82
Torque Wrenches & Torque Accessories _____	84
Loose Nut Prevention _____	93
Wheel Centering Products _____	96
Lug Nut Removal Products _____	98
Wheel Attaching Hardware _____	102
Tire & Wheel Service Tools _____	106
Stud & Brake Hub Cleaning Tools _____	110



CONTENTS (cont.)

111 LIFTING EQUIPMENT

Portable Bottle Jacks _____	113
Service Jacks _____	119
Jack Stands _____	132
Specialty Jacks _____	136
Transmission Jacks _____	139
Wheel Dollies _____	143
Vehicle Stands & Accessories _____	148
Hydraulic Shop Presses _____	149
Shop Cranes _____	151
Brake Drum Handlers _____	153

155 TIRE & WHEEL SERVICE

Tire Lubricants & Sealants _____	158
Markers _____	163
Tire Branders _____	164
Bead Breakers _____	166
Hydraulic Pumps, Hydraulic Rams _____	170
OTR Service Tools _____	172
Cribbing Sets _____	174
Bead Seating Devices _____	175
Beadkeepers _____	180
Chloride Pumps _____	181
Tire Irons _____	182
Small Mount/Demount Tools _____	186
Lock Ring Tools _____	187
Heavy Duty Hammers _____	188
General Purpose Hammers & Wedges _____	189
Replacement Handles _____	190
Wrenches & Lug Wrenches _____	191
Shop Service Tools _____	193
Automatic Tire Inflation Systems _____	195
Safety Inflation Cages _____	196

201 VALVE HARDWARE

TPMS Best Practices _____	205
TPMS Relearn Chart _____	206
TPMS Sensor Activation Tools _____	207
TPMS Accessories & Kits _____	216
TPMS Tools _____	223
Banded TPMS Systems _____	227
Schrader TPMS Transmitters _____	228
Dill TPMS Transmitters _____	230
EZ-Sensor & REDI-Sensor TPMS Transmitters _____	232
HUF Intellisens Universal Sensors _____	233
Smart Sensor Pro+ _____	234
TPMS Retrofit Kits, Trailer TPMS Systems _____	236
TPMS Training & Promotional Materials _____	237
TPMS Cabinets _____	239
Tubeless Tire Valves (Passenger) _____	240
Tubeless Tire Valves (Truck) _____	241
Truck & Specialty Valves _____	242
Valve Caps, Cores & Extensions _____	246
Special Application Products _____	249
Air/Liquid/Agricultural Valves _____	250
Large Bore Valves _____	252
Large Bore Extensions _____	259
Z-Bore Valve System _____	260
PT Valve System _____	261
Valve Hardware Tools _____	262
Tire Gauges & Chucks _____	264
Inflator Gauges _____	275



CONTENTS (cont.)

281 SERVICE EQUIPMENT

Passenger Tire Changers _____	283
Passenger & Light Truck Tire Changers _____	290
Tire Changer Accessories _____	292
Heavy Duty Tire Changers _____	296
Heavy Duty Tire Changer Accessories _____	299
Wheel Balancers _____	301
Wheel Balancer Accessories _____	308
Brake Lathes _____	318
Brake Lathe Accessories & Adapters _____	321
Lifts _____	330
Rubber Blocks & Lift Pads _____	336
Rolling Jacks & Work Stations _____	337

339 WHEEL BALANCING SUPPLIES

Passenger Car Wheel Weights _____	341
Truck Wheel Weights _____	349
Adhesive Wheel Weights _____	353
Wheel Weight Kits _____	360
Wheel Weight Tools _____	363
Tire Balancing Compounds _____	366

371 ALIGNMENT

EZ-Shims™, EZ-Cam™ XR Camber Kits _____	372
Passenger Car Alignment Accessories _____	373
Camber/Caster Tools _____	374
Alignment Tools & Systems _____	386

393 AUTO & FLEET SERVICE EQUIPMENT

Battery Chargers & Testers _____	394
Service Equipment _____	396
Exhaust Hoses & Tailpipe Adapters _____	398
Vehicle Exhaust Extraction _____	399
Bench Grinders & Shop Vises _____	400
Pliers & Screwdrivers _____	401
Shop Cleaners & Brushes _____	402
Shop Lights & Service Stickers _____	404
Tire Displays, Racks & Carts _____	405
Interior Protection Products _____	409
Stud Guns & Studding Equipment _____	412
Fluid Pumps _____	413
Drains & Grease Guns _____	414
Waste Oil Drains _____	415
Oil Accessories _____	417
Safety Products _____	418
Wheel Chocks _____	420
Rubber Blocks & Lift Pads _____	421
Mechanic's Gloves _____	422



CONTENTS (cont.)

423 FLUID EXCHANGE

Refrigerant Handling Systems _____	424
Fluid Exchangers & Flushers _____	427
Fluid Exchange Accessories _____	428

429 TIRE REPAIR MATERIALS

Tire Repair Cabinets & Kits _____	431
Cements, Sealants & Patches _____	432
Thermopress & Extruders _____	460
Monaflex Tire Repair System _____	461
Air Buffers & Drills _____	462
Tire Repair Tools & Accessories _____	464
Tire Spreaders & Repair Stations _____	476

483 RETREADING

Rasp Blades & Spacers _____	484
Retread Accessories _____	491
Retread Consumables _____	495
Tire Appearance _____	496
Envelopes _____	498
Retread Related Items _____	500

MEASUREMENT CONVERSION CHART _____ 501

ALPHABETICAL INDEX _____ 502

NUMERIC INDEX _____ 518

ASCOT SUPPLY CORP. IS NOT RESPONSIBLE FOR INADVERTENT TYPOGRAPHICAL ERRORS OR OMISSIONS.

- Tire and Rim Servicing can be dangerous, and should be done by trained personnel using proper tools and procedures. The Occupational Safety and Health Administration has a safety standard for the servicing of single-piece and multi-piece rim wheels (OSHA std 29 CFR 1910.177) to include requirements for the safe servicing of rims used on passenger, truck, trailers, buses and off-road vehicle equipment. Properly trained personnel should perform all tire servicing. Failure to comply with these procedures as well as procedures recommended by Tire Manufacturers and Wheel and Rim Manufacturers may result in faulty positioning of the tire and or rim and may cause the assembly to burst with explosive force sufficient to cause serious physical injury or death.
- The sole intent of this catalog is to aid the Ascot Distributors and their customers in the resale of automotive related parts. This catalog, or any part thereof, may not be reproduced in any form without written consent from Ascot Supply Corp.
- Ascot and the "Ascot Logo" are marks of Ascot Supply Corporation. The products in this catalog are manufactured for distributors of Ascot Supply Corp. and their customers.
- Caution and Warning statements appear throughout this catalog. Use of products in this catalog contrary to specifications and directions may result in personal injury and/or property damage.
- **WARRANTY DISCLAIMER:** Ascot Supply Corp. has made a diligent effort to illustrate and describe the products in this catalog accurately; however, illustrations, photos and descriptions are for the sole purpose of identification and do not express or imply a warranty that the products are merchantable, or fit for a particular purpose, or that the products will necessarily conform to the illustrations, photos or descriptions. Ascot Supply Corporation or its Distributors make no warranty or affirmation of fact, express or implied.
- Lead is harmful if ingested. Wash thoroughly after handling and before eating, drinking or smoking. Keep away from children and pets.
- O.S.H.A. HAZARDOUS SUBSTANCE AND CALIFORNIA PROPOSITION 65 PRODUCT INFORMATION: Material Data Safety Sheets for products containing OSHA defined hazardous substances and a list of products known to the state of California to cause cancer, birth defects, or other reproductive harm are available upon request from Ascot Supply Corp.
- Ascot Supply Corp. disclaims all express and implied warranties, including the implied warranties of merchantability and fitness for a particular purpose. Ascot Supply Corp. also disclaims liability for personal injury, property damage or consequential damages.
- **IMPORTANT:** Snap-In passenger valve stems are safe for tire pressures up to a maximum of 60 psi (cold tire pressure) and for a maximum rim thickness of .156" (3.96mm). If greater pressure or rim thickness is required, metal clamp-in valve stems are recommended.
- Ascot Supply Corp. Does Not recommend "temporary" tire repairs. All repairs should perform the function of filling or replacing the injured section as recommended by the RMA and other industry associations.
- Always wear eye protection when using air tools, wheels, cups and rasps.
- **WARNING:** Always wear safety goggles when using striking or struck tools. Never use one hammer to strike another hammer. Never use a striking tool with a loose or damaged handle. Discard any striking or struck tool if it shows dents, cracks, chips or mushrooming.
- **CAUTION:** Use all chemicals and cements in a well ventilated area. Avoid prolonged breathing or inhalation of vapors.
- For best results, check tire pressure when tires are cold or when the vehicle has not been driven for several hours. Readings taken after prolonged driving at high speeds will increase tire pressure causing a false reading. Check tire pressure at least once a week or as necessary.